Installation Instructions _____

MT050B DryLine[®] DEHYDRATOR DRYING MEMBRANE REPLACEMENT KIT





FILTER BOWL AND DRYER TUBE SUB-ASSEMBLY

- Install #6-32 Tinnerman clips onto filter bowl mounting bracket so that the clips snap into place with the curved lip on the filter bowl side.
- 2. Wrap male threads on check-valve side of filter bowl assembly with PTFE tape (included). Screw assembly into dryer tube input until hand-tight.
- 3. Wrap threaded end of the 3/8" compression fitting with PTFE tape. Screw compression fitting into output side of dryer tube.

MT050B DryLine[®] DEHYDRATOR DRYING MEMBRANE REPLACEMENT KIT



DRYER TUBE AND FILTER BOWL INSTALLATION

- 1. Ensure that the filter bowl and dryer tube subassembly is complete as shown to the left.
- 2. Slide the end of the cable ties through the slots in the saddle mounts. Wrap the white nylon cable ties around the dryer tube.
- 3. Fasten the filter bracket to the chassis using #6-32 screw assemblies, or #6-32 screws with #6 flat and lock washers.
- 4. Tighten the cable ties around the dryer tube. Trim off excess part of cable ties.
- 5. Attach compressor output hose to the 5/16 barbed fitting on the filter bowl input.
- 6. Slide two 1/4" hose clamps onto the solenoid drain hose. Attach the solenoid drain hose to 1/8" barb on bottom part of filter bowls and solenoid input barb.



Customer Support Center From North America Telephone: 1-800-255-1479 Fax (U.S.A.): 1-800-349-5444 International Telephone: +1-779-435-6500 Fax Number: +1-779-435-8579 Web Access Internet: www.commscope.com Email: #prc@commscope.com

All designs, specifications and availability of products and services presented in this bulletin are subject to change without notice.

Bulletin AE01B-A0536-002 Rev C (10/11) © 2008 - 2011 CommScope, Inc. All rights reserved CommScope, 3 Westbrook Corporate Center, Suite 900 Westchester, IL 60154 USA